



Exchange of bearing LANG Clutch KK73.1.




- As soon as the clutch is dismantled from the compressor, the dismantling tool is to be fixed on the clutch as shown. (Drawing of the tool can be required by mail: info@ealang.com)

- Remove both safety rings and the protection plate.



- Screw the M8 (or M6) Screws in the threads (max. 8mm into) – screw until contact and rotate one revolution back.





- Screw in the M16 screw until the pulley can be removed from the rotor.


<p>Diameter max. 83,8 mm</p> <p>Diameter min. 70 mm</p> <p>Diameter Min. 91 mm</p>	<ul style="list-style-type: none"> • Use two tubes (see dimensions in the draft) to press out the bearing from the pulley <p>Press on the outer ring</p>
--	---


<p>$F_{max} = 21kN$</p>	<ul style="list-style-type: none"> • Press the new bearing into the pulley <p>Press the new bearing on the OUTER RING</p>
------------------------------------	--


<p>$F_{max} = 21kN$</p>	<ul style="list-style-type: none"> • Press the bearing until contact
------------------------------------	---

	<ul style="list-style-type: none"> • Press the bearing – Pulley assembly on the rotor with a tube (see dimensions in the draft) <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>Press the bearing on the INNER RING</p> </div>
---	---

	 <p>Press the bearing until contact</p>
--	--

	<ul style="list-style-type: none"> • Set the Safety ring the bearing outer ring • Assemble the protection plate • Set the Safety ring the bearing inner ring
---	---

	<ul style="list-style-type: none"> • Check the air gap with a feeler gauge • Turn the clutch by hand; check that no rubbing noise can be noticed.
---	---

	<ul style="list-style-type: none"> • Lubricate the cone with fitting grease (Molycote P40 or OKS 250 – observe manufacturers' instructions!) • Assemble the clutch on the compressor and fix it
--	---