
TransArctic Canada Inc.


Product Number Line Component Product	Description  H Description	Bin	Date Unit	Weight Qty	Uof M	Yield
KMC51371	Mt Kit, ISB, 5.9L, BBCV, 1 TM-21, '06		7/13/2006	39.04		0
10 BEL61295	Belt, 6gr, 1295mm (51.0") (5060510)		each	1		
20 BMC59040	Bkt, Main, Weldmt, ISB, Conv		each	1		
30 BMC59038	Bkt, Main, Spacers, Block, ISB, Conv		each	1		
40 BMC59039	Bkt, Brace, Diag, D/S, Sup, ISB, Conv		each	1		
50 SCD22410	Spacer, Col, Drl,122.38mm x25.4o x10.32i		each	1		
60 PUL81074	Pulley, Idler, Frontside, P8,74d (89103)		each	1		
70 TEN80002	Tenr, HD Spring, BackSide, CCW (89200A)		each	1		
80 KBC51371	Bag Kit, Fasteners, KMC51371/KMC51071		each	1		

TransArctic Canada Inc.


Page 1 of 1

Product N	Number Component Prod#	<b>Description</b> Description	Bin	Date Unit	Weight Qty	Uof M	Yield
KBC5137	71	Bag Kit, Fasteners, KMC51371/KMC51071		3/31/2006	1.39		0
10 H	BTS10001	Bolt, Shoulder, 10mm (89064)		each	1		
12 H	BTC10150	Bolt, Hex, 10 x 1.5 x 150mm, 10.9, Plt		each	1		
15 H	BTC10080	Bolt, Hex, 10 x 1.5 x 80mm, 10.9, Plt		each	1		
17 H	BTC10060	Bolt, Hex, 10 x 1.5 x 60mm, 10.9, Plt		each	2		
20 H	BTC10040	Bolt, Hex, 10 x 1.5 x 40mm, 10.9, Plt		each	1		
30 H	BTC10030	Bolt, Hex, 10 x 1.5 x 30mm, 10.9, Plt		each	5		
40 H	BTC08100	Bolt, Hex, 8 x 1.25 x 100mm, 10.9, Plt		each	4		
50 H	BTC08090	Bolt, Hex, 8 x 1.25 x 90mm, 10.9, Plt		each	2		
60 H	BTC08065	Bolt, Hex, 8 x 1.25 x 65mm, 10.9, Plt		each	1		
80 1	NTA10000	Nut, Hex, 10 x 1.5, 8.8, Plt		each	1		
100 V	WFA08000	Washer, Flat, 8mm, 8.8, Plt		each	4		
105 V	WFA10000	Washer, Flat, 10mm, 8.8, Plt		each	1		
110 V	WLA08000	Washer, Lock, 8mm, 8.8, Plt		each	7		
120 V	WLA10000	Washer, Lock, 10mm, 8.8, Plt		each	10		
























Install bolts finger tight to hold in place then put on Main Bracket

## TransArctic A/C Compressor Mount Installation Disclaimer

All compressor mounts should be installed by qualified and trained personnel using proper tools and equipment in safe working conditions following industry standard guidelines for motor vehicle service and repair.

The installer of any compressor mount purchased from TransArctic must undertake all responsibility of issues arising from that compressor bracket being installed on any vehicle. Mount functionality, operation and durability can all be compromised by an incompetent installation.

Due to the many different situations, parameters and application criteria, which are beyond the compressor mount manufacturer's control, TransArctic does not warrant design, durability, or operational functionality of any compressor mount improperly installed by another party.

With no implied guarantees it is the mount installer's strict responsibility to determine safety and functionality, of the compressor mount, at the time of installation.

Please contact TransArctic with any issue arising from installation so we may better improve the product. If you have any reservations about the compressor mount integrity contact TransArctic immediately at 1-877-COLD-AIR.