Bill of Materials Listing

TransArctic Canada Inc.

					-
Product Number Line Component Prod	Description # Description	Bin	Date Unit	Weight Uof M _{Qty}	Yield
KMC52652	Mt Kit, ISB, A3FE, 2 TM-21, '06-'07		7/26/2006	12.99	0
10 BEL11138	Belt, A gr, 1138mm (44.8") (17448)		each	1	
20 BMC59033	Bkt, Main, Weldmt, ISB, A3FE		each	1	
30 BMC59035	Bkt, Cradle, BTM, 87mm, ISB, A3FE		each	1	
40 BMC59037	Bkt, Spacer, Bar, ISB, A3FE		each	1	
50 PUL10094	Pulley, Idler, SA,94d x 18w,Blk (IP-103)		each	1	
60 SCD12717	Spacer, Col, Drl, 12.7mm x 25.40 x17i		each	1	
70 SLV17010	Sleeve, Pulley, 16.90 x 22.23mm x 10.32i		each	1	
80 TEN00002	Tenr,Spring,Un-Direct,90d,3/8 x4.5"/3.5"		each	1	
90 KBC52652	Bag Kit, Fasteners, KMC52652/2352/2052		each	1	


4/4/2007 Page 1 of 1

Bill of Materials Listing

TransArctic Canada Inc.

	Number Component Prod#	Description Description	Bin	Date Unit	Weight _{Qty}	Uof M	Yield
KBC526	552	Bag Kit, Fasteners, KMC52652/2352/2052		7/26/2000	6 1.34		0
10	BTC10050	Bolt, Hex, 10 x 1.5 x 50mm, 10.9, Plt		each	2		
20	BTC10045	Bolt, Hex, 10 x 1.5 x 45mm, 10.9, Plt		each	1		
25	BTC10040	Bolt, Hex, 10 x 1.5 x 40mm, 10.9, Plt		each	1		
30	BTC08100	Bolt, Hex, 8 x 1.25 x 100mm, 10.9, Plt		each	8		
40	BTC08040	Bolt, Hex, 8 x 1.25 x 40mm, 10.9, Plt		each	1		
50	BTC08035	Bolt, Hex, 8 x 1.25 x 35mm, 10.9, Plt		each	1		
60	BTC08015	Bolt, Hex, 8 x 1.25 x 15mm, 10.9, Plt		each	1		
70	CSF06250	Capscrew, FH, 3/8-16 x 2.5", 9, Plt		each	1		
80	NTA10000	Nut, Hex, 10 x 1.5, 8.8, Plt		each	1		
90	WFA08000	Washer, Flat, 8mm, 8.8, Plt		each	11		
100	WFA10000	Washer, Flat, 10mm, 8.8, Plt		each	4		
110	WLA08000	Washer, Lock, 8mm, 8.8, Plt		each	11		
120	WLA10000	Washer, Lock, 10mm, 8.8, Plt		each	4		

4/3/2007 Page 1 of 1




KMC52652 / KMC52352 / KMC52052 - Mt Kit, ISB, 5.9L/6.7L, A3FE, 2 TM-21/TM-16 or 1 TM-16 & 1 TM-21, '06-'07

Remove Radiator and intercooler.

EGR Clamp may need to be rotated so the bolt clears tensioner swing path.

Engine wire harness may need to be moved and re-clamped to accommodate lower mount bracket



Main Power Conductors have to be secured firmly to engine so that tensioner does not hit them.

TransArctic A/C Compressor Mount Installation Disclaimer

All compressor mounts should be installed by qualified and trained personnel using proper tools and equipment in safe working conditions following industry standard guidelines for motor vehicle service and repair.

The installer of any compressor mount purchased from TransArctic must undertake all responsibility of issues arising from that compressor bracket being installed on any vehicle. As well as insure that a **proper and sufficient ground** is established between the compressors' clutches and the vehicle's engine. Mount functionality, operation and durability can all be compromised by an incompetent installation.

Due to the many different situations, parameters and application criteria, which are beyond the compressor mount manufacturer's control, TransArctic does not warrant design, durability, or operational functionality of any compressor mount improperly installed by another party.

With no implied guarantees it is the mount installer's strict responsibility to determine safety and functionality, of the compressor mount, at the time of installation.

Please contact TransArctic with any issue arising from installation so we may better improve the product. If you have any reservations about the compressor mount integrity contact TransArctic immediately at 1-877-COLD-AIR.