
TransArctic Canada Inc. 3/31/2008
Page 1 of 1


Product Number Line Component F	Description Prod# Description	Bin	Date Unit	Weight Uof M _{Qty}	Yield
KMN84521	Mt. Kit, MForce DT, FE300, 2 TM-21,07		08/30/04	15.85	0
10 BMN80034	Bkt, Comp, Upper, CE200		each	1	
20 BMN80035	Bkt, Comp, Lower, CE300		each	1	
30 BMN80049	Bkt, Idler, Weldment, FE300		each	1	
31 BMN80038	Bkt, Rad Hose, PMax DT, CE300		each	1	
50 PUL80074	Pulley, Idler, B/S, Wide, 76d (89102)		each	2	
52 BEL02743	Belt, 10gr, 2743mm (108")		each	1	
60 KBN84521	Bag Kit, Fasteners, KMN84521		each	1	
61 BMS16022	Bkt, TM-16 Spacer Plate		each	4	
62 SCD14010	Spacer, Col, Drl, 14mm x25.4o x10.32i		each	1	
72 CLP20040	Clamp, "P" type, #40, 1/2"w, 2 1/2", PC		each	1	
82 CLP36001	Clamp, Gear, #36,1 13/16-2 3/4 (46/70mm)		each	2	

TransArctic Canada Inc.

3/31/2008
Page 1 of 1

Yield	Uof M	Weight _{Qty}	Date _{Unit}	Bin	Description rod# Description	Product Number Line Component P
0		1.56	05/03/07		Bag Kit, Fasteners, KMN84521	KBN84521
		4	each		Bolt, Hex, 8 x 1.25 x 100mm, 10.9, Plt	10 BTC08100
		4	each		Bolt, Hex, 8 x 1.25 x 140mm, 10.9, Plt	20 BTC08140
		4	each		Bolt, Hex, 8 x 1.25 x 110mm, 10.9, Plt	21 BTC08110
		1	each		Bolt, Hex, 10 x 1.5 x 40mm, 10.9, Plt	30 BTC10040
		1	each		Capscrew, FH, 10 x 1.5 x 45mm, 10.9,Plt	40 CSF10046
		8	each		Washer, Flat, 8mm, 8.8, Plt	50 WFA08000
		9	each		Washer, Lock, 8mm, 8.8, Plt	60 WLA08000
		1	each		Nut, Hex, 8 x 1.25, 8.8, Plt	63 NTA08000
		1	each		Washer, Flat, 10mm, 8.8, Plt	70 WFA10000
		1	each		Washer, Lock, 10mm, 8.8, Plt	80 WLA10000
		2	each		Bolt, Shoulder, 10mm (89064)	90 BTS10001
		2	each		Washer, Dust Cover (89060)	100 WDS17001
		1	each		Bolt, Hex, 1/4-20unc, .75", 5, Plt	130 BTP04075
		1	each		Nut, Hex, 1/4-20unc, 5, Plt	140 NTP04000
		1	each		Washer, Flat, 1/4", 2, USS, Plt	150 WFS04003





KMN84520 - Mt. Kit, MForce DT, FE300, 2 TM-21/TM-16



Rad hose is reversed and hose is supported from Rad shroud.

TransArctic A/C Compressor Mount Installation Disclaimer

All compressor mounts should be installed by qualified and trained personnel using proper tools and equipment in safe working conditions following industry standard guidelines for motor vehicle service and repair.

The installer of any compressor mount purchased from TransArctic must undertake all responsibility of issues arising from that compressor bracket being installed on any vehicle. As well as insure that a **proper and sufficient ground** is established between the compressors' clutches and the vehicle's engine. Mount functionality, operation and durability can all be compromised by an incompetent installation.

Due to the many different situations, parameters and application criteria, which are beyond the compressor mount manufacturer's control, TransArctic does not warrant design, durability, or operational functionality of any compressor mount improperly installed by another party.

With no implied guarantees it is the mount installer's strict responsibility to determine safety and functionality, of the compressor mount, at the time of installation.

Please contact TransArctic with any issue arising from installation so we may better improve the product. If you have any reservations about the compressor mount integrity contact TransArctic immediately at 1-877-COLD-AIR.