


## Passenger A/C Controls



**On/Off Button:** Press to turn on/off power to controls. Display will flash software revision & then interior temperature.

**Cool Pad:** Press cool pad (2) to start the a/c system. If interior temperature is higher than set point temperature cooling will start. Red LED at (2) will light. If interior temperature is lower than set point temperature fans will come on and coach heat will need to be adjusted.

**Raise and Lower Set Point Temperature:** Pad (3) will raise and pad (4) will lower set point temperature. Set Point temperature viewed on screen when either up or down arrow pad pushed.

**Fan Speed Adjustment:** Three speed fans adjusted at Pad (6) and displayed speed on screen. **Fans adjusts automatically as interior temperature approaches set point temperature.**